Assembly and use

p-marc Footvolley Pack

This manual covers assembly and use of the p-marc Footvolley Pack. Follow the blocks in order and choose the method for your clamp. The pack includes one black storage bag.

If you selected both clamps, use the procedure for the type of post where you will install each product.

1 · p-marc Beach Sports Scoreboard

Standard clamp, larger-post clamp, set markers and rear supports.

2 · p-marc Customizable Flag

Standard clamp and clamp for larger posts.

3 · p-marc Footvolley Ball Holder

Standard clamp and clamp for larger posts.

4 · p-marc 3-pack hooks

Hangers for standard posts, larger posts and parasols.

IMPORTANT

Always tighten the screws by hand and do not force them.

p-marc Beach Sports Scoreboard

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Clamp for standard posts


Complete game scoreboard assembly.

STEP 1



Bring the standard clamp up to the post.

STEP 2



Place it around the post and align the holes.

STEP 3



Insert the fixing screw and start turning it.

STEP 4



Tighten the screw.

STEP 5



Insert the scoreboard vertically into the slot in the clamp.

STEP 6



Slide it until it is fully fitted and properly aligned.

p-marc Beach Sports Scoreboard

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Clamp for standard posts · continued


Complete game scoreboard assembly.

STEP 7




For extra support, add the second screw and tighten it.

STEP 8




Fit a set marker into the hole below the numbers.

STEP 9



Place both set markers horizontally below the numbers.

STEP 10



To show a set won, remove the relevant team's set marker and refit it vertically.

p-marc Beach Sports Scoreboard

306 · p-marc Footvolley Pack | Assembly and use | EN V3

CLAMP FOR LARGER POSTS

Alternative fastening with a hook-and-loop strap only.

STEP 1



Thread the hook-and-loop strap through one clamp handle, with the slot facing upwards, as shown.

STEP 2



Fold the strap back onto itself and secure it firmly around the handle you threaded it through.

STEP 3



Place the clamp next to the post and wrap the strap all the way around the post.

STEP 4



Thread the free end through the other handle and pull firmly until the clamp fits snugly around the post.

STEP 5



Fasten the strap onto itself. Then fit and slide the scoreboard into the slot. The second screw is only for the standard clamp.


p-marc Beach Sports Scoreboard

306 · p-marc Footvolley Pack | Assembly and use | EN V3

SET MARKERS

Fitting both markers and using them to show a set won.

STEP 1



Find the set marker mounting area below the numbers.

STEP 2



Find the small holes where each set marker fits.

STEP 3




Identify the two set markers, one for each colour.

STEP 4



Fit each marker into its hole and place it horizontally below the numbers.

STEP 5



To show a set won, remove the relevant team's marker and refit it vertically.

p-marc Beach Sports Scoreboard

306 · p-marc Footvolley Pack | Assembly and use | EN V3

REAR SUPPORTS

Fitting the supports from the back of the scoreboard.

STEP 1



Identify the back of the scoreboard, the side without the logo.

STEP 2



Find the small rectangular slots on the right and left.

STEP 3



Identify the two hanger pieces.

STEP 4



Insert each hanger from the back into its rectangular slot until it fits securely.

p-marc Customizable Flag

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Clamp for standard posts


Complete assembly: attaching the clamp and fitting the product.

STEP 1



Bring the standard clamp up to the post.

STEP 2



Place it around the post and align the holes.

STEP 3




Insert the fixing screw and start turning it.

STEP 4



Tighten the screw.

STEP 5



Insert the flag vertically into the slot in the clamp.

STEP 6



Slide it until it is fully fitted and properly aligned.

p-marc Customizable Flag

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Clamp for standard posts · continued

Complete assembly: attaching the clamp and fitting the product.

STEP 7



For extra support, add the second screw and tighten it.

STEP 8



The customizable flag is assembled and ready to use.

p-marc Customizable Flag

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Clamp for larger posts

Alternative fastening with a hook-and-loop strap only.

STEP 1



Thread the hook-and-loop strap through one clamp handle, with the slot facing upwards.

STEP 2



Fold the strap back onto itself and secure it firmly around the handle you threaded it through.

STEP 3



Place the clamp next to the post and wrap the strap all the way around the post.

STEP 4



Thread the free end through the other handle and pull until the clamp fits snugly around the post.

STEP 5



Fasten the strap. Then fit and slide the flag into the slot. The second screw is only for standard-clamp assembly.

p-marc Footvolley Ball Holder

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Clamp for standard posts

Fit the ring and place the Footvolley ball. Screw and nut are mandatory.

STEP 1



Place the standard clamp on the post.

STEP 2



Press the clamp until it fits securely around the post.

STEP 3



Fit the screw and nut: both are mandatory.

STEP 4



Align the ring connector with the slot in the clamp.

STEP 5



Slide the ring until its connector is fully fitted into the slot.

STEP 6



The holder is assembled and ready to use.

p-marc Footvolley Ball Holder

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Clamp for standard posts · continued

Fit the ring and place the Footvolley ball. Screw and nut are mandatory.

STEP 7



Place the Footvolley ball in the holder.

p-marc Footvolley Ball Holder

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Clamp for larger posts

Approx. 6-14 cm. No screw or nut. For larger posts, contact p-marc.

STEP 1



Thread the hook-and-loop strap through one clamp handle, with the slot facing upwards.

STEP 2



Fold the strap back onto itself and secure it firmly around the handle you threaded it through.

STEP 3



Place the clamp next to the post and wrap the strap all the way around the post.

STEP 4



Thread the free end through the other handle and pull firmly until the clamp fits snugly around the post.

STEP 5



Fasten the strap onto itself. The clamp is securely attached to the post and ready to use.


p-marc 3-pack hooks

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Standard-post hanger


1 hanger + 1 screw.

STEP 1



Place the hanger on the court post.

STEP 2



Press and adjust the piece until it fits securely.

STEP 3



Insert the screw for extra support.

STEP 4



The hanger is assembled and ready to use.

STEP 5



Use the lower ring to hang small objects, such as glasses.

STEP 6



Use the main hook to hang a towel, T-shirt, phone, speaker or other suitable objects.

p-marc 3-pack hooks

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Hanger for larger posts

Approx. 6-14 cm. For larger posts, contact p-marc about a longer strap.

STEP 1



Thread the hook-and-loop strap through one hanger handle, as shown.

STEP 2



Fold the strap back onto itself and secure it firmly around the handle you threaded it through.

STEP 3



Place the hanger next to the post and wrap the strap all the way around the post.

STEP 4



Thread the free end through the other handle and pull firmly until the hanger fits snugly around the post.

STEP 5



Fasten the strap onto itself. The hanger is securely attached to the post and ready to use.

p-marc 3-pack hooks

306 · p-marc Footvolley Pack | Assembly and use | EN V3

Parasol hanger


1 hanger + 1 screw.

STEP 1




Place the hanger on the parasol pole.

STEP 2




Press and adjust the piece until it fits securely.

STEP 3



The hanger is fitted onto the parasol pole.

STEP 4



Insert the screw for extra support.

STEP 5



Use the lower ring to hang small objects, such as glasses.

STEP 6



Use the main hook to hang a towel, T-shirt, phone, speaker or other suitable objects.